

SEARCH MODES



QUICK START



This Getting Started Guide, the User Manual and translations are available to download online.



- EN English
- CZ čeština
- DE Deutsch
- EL ελληνικά
- HI हिन्दी
- ID Bahasa Indonesia
- IT Italiano
- JP 日本語
- KR 한국어
- PT Português
- RU русский
- TR Türkçe
- ZH 中文


minelab.com

X-TERRA ELITE

GETTING STARTED GUIDE




ASSEMBLY



CHARGING

5-6 HOURS



⚠ Charge your detector with a good-quality USB charger that has a minimum charging capacity of 2A @ 5V. Risk of USB charger failure if a low quality charger is used.

Look for the marks below on USB chargers.

CONTROLS & DISPLAY

